



L2301-AW

Wireless Level Gauge

Quick Start Guide

Meet your Level-Up



L2301-AW

Wireless Level Gauge



1 Installation


Install the unit inside the caravan making sure that the yellow arrows on the unit points to the correct direction.



Ensure to install the unit with the charging port accessible.

2 Power On


Press the **On** button on the unit to switch on, the blue **LED** will come on. Press it again to initiate the wifi hotspot. Wait for the blue **LED** to start flashing.



The flashing blue LED indicates that the unit has opened a wifi hotspot.

3 Connect to hot spot

Open your phone's wifi settings, find the "levelup" hotspot and connect to it. The default wifi password is **12345678**.



NOTE: if the connection drop within a few seconds, check your phone's wifi settings and disable "drop wifi without internet connection" or similar setting.


4 Browse to GUI

Open your mobile device browser and scan the URL QR code bellow.



5 Initial Settings

Enter the name that you want to use for your wireless level gauge hotspot. This will be the wifi hotspot and password that will be unique to your wireless level gauge.



Please enter the WiFi name for your unit's hotspot:

Password:

Confirm Password:

Submit

Type the wifi hotspot name for your level-

Type the password for you level-up's

6 Reconnect and start levelling

Repeat steps 2 and 3 above, this time connecting to the hotspot name that you entered in step 5

Repeat step 4 above and start using the wireless level gauge.



7 Calibration

After installation the unit can be calibrated, if necessary, by following these steps:

- a) Use a spirit level or bubble level to setup your caravan to be perfectly level
- b) If your Level-Up does not show 0° on both gauges, repeat steps 6, this time in step 4 scan the calibration QR code below:



- c)The unit will take approx. 1 to 2 minutes to calibrate, after which both gauges will show spot on values of 0° and the centre display indicates “LEVEL”

Need Help?

Visit our website and check out support videos or send e-mail

www.level-up.org.za

support@level-up.org.za